



Installation Instructions for a Flush Mount Seat

Note: This is a premium product!

Please use caution at all stages of installation!

1. Once the Seat has been removed from the box, remove 5/16"-18 hex cap screws in rear of seat that hold the seat to the Flush Mount Adapter.
2. Place seat somewhere safe and preferably on something soft (e.g. foam, shipping blanket, etc.).
3. Securely install the Flush Mount Adapter at the desired location.
4. Replace seat onto Adapters, front first and secure in rear with screws provided!

Refer to the Seat Manual provided for more information
about the operation and maintenance of
your STIDD Seat.

Any questions, please contact:
STIDD Systems Customer Service
vox: 631.4772400, ext. 135
email:CustomerService@stidd.com